

General Instructions for use of KLEEN KOTE™ 108 Asphalt Release

REV. 022513

Call (800) 801.7832 or visit www.4progressive.com for further information, detailed instructions, MSD sheets or special assistance.

SURFACE/EQUIPMENT PREPARATION

Clean all application equipment and dispensing containers prior to using/dispensing KLEEN KOTE. Remove all previously used release agents from the equipment prior to applying KLEEN KOTE. This will eliminate any adverse reaction between KLEEN KOTE and any former release agents. For Best results, spray the entire paver, truck or other equipment with KK108 the night before you pave. If you cannot apply KK 108 the night before your next pave, you can apply KK 108 just prior to use, **BUT, KK 108 MUST TURN FROM WHITE TO CLEAR AFTER IT IS SPRAYED ON THE EQUIPMENT BEFORE YOU PAVE.** Do NOT reapply KK 108 in the morning if you have already applied it the night before. By spraying again, it will weaken the grip of the first application.

APPLICATION

KLEEN KOTE may be applied at any time. The surface does not need to be dry however the product CANNOT be applied in the rain. Spray KK 108 and let the product change from white to clear before using. Reapply KLEEN KOTE every night regardless of whether or not you clean the machine prior to its next use. To prevent lock up in cool weather, apply KK 108 to the edges of the feeder track **WHILE THE FEEDER TRACK IS RUNNING.**

COVERAGE RATES

1 gallon (3.78 liters) of KLEEN KOTE will cover approx. 1,000 - 2,000 sq. feet (185 sq. meters) depending on the surface type. Spray on for best performance and ease of application.

IMPORTANT INFORMATION

Never dispense KLEEN KOTE in a drum or container previously used to store acid. Do not use an applicator or sprayer used for acid. The acid residue cannot be removed from the drum, container or applicator and will cause KLEEN KOTE to separate. DO NOT mix KLEEN KOTE with other release agents or chemicals.

Harsh chemicals are not needed to remove KLEEN KOTE. Soap and water can be used when required. Reapply KLEEN KOTE after every use and after every wash.

KLEEN KOTE deposits a thin film of barrier protection. DO NOT remove the asphalt build-up from paver or other equipment during the paving process. This will remove the applied KLEEN KOTE, causing the fresh layer of asphalt to stick to the paver. KLEEN KOTE must be re-applied to all areas of the paver where asphalt was removed and can be re-applied at any time during the paving process.

***PREVENT KLEEN KOTE FROM FREEZING!
DO NOT MIX WITH OTHER RELEASE AGENTS OR CHEMICALS!***

FIRST AID PROCEDURES

If contact with eyes occurs, immediately flush with water. If swallowed, do NOT induce vomiting. In either case seek medical attention immediately. Additional information is available on the MSD sheet.

WARNINGS

Please keep this and all chemicals out of reach of children! Use this product only as directed. Non-stick product may cause slipperiness on vehicle controls and surfaces. Avoid spraying on braking surfaces where slipperiness may cause loss of control.