

GENERAL INSTRUCTIONS FOR KLEEN KOTE™ 111 EQUIPMENT PROTECTION

REV. 022513

General Instructions for KLEEN KOTE™ 111 Equipment Protection

Call (800) 801.7832 or visit www.4progressive.com for further information, detailed instructions, MSD sheets or special assistance.

SURFACE/EQUIPMENT PREPARATION

Clean all application equipment and dispensing containers prior to using/dispensing KLEEN KOTE. For best results, clean the application surface and remove all previous release agents, acids and chemicals prior to applying KLEEN KOTE to eliminate any adverse reaction between KLEEN KOTE and the former release agent, acid or chemicals. In freezing weather, the surface must be warmed indoors prior to applying KLEEN KOTE.

APPLICATION

KLEEN KOTE may be applied at any time. The surface does not need to be dry however the product CANNOT be applied in rain, ice or snow. For ready mix, concrete pumping and belt trucks: Spray KK 111 over the entire truck before EVERY load with attention to areas of heavy concrete contact. Allow it to turn from white to clear before use. If truck is washed, you must re-apply KK 111 before use. If concrete is removed from any area of the vehicle, re-apply KK 111. For concrete paving machines: Spray the entire machine with KK 111 the night before you pour. If you cannot spray the machine the night before you can spray just before use. Allow KK 111 to turn from white to clear before use. For all equipment, tools and vehicles: Spray on KK 111 and let it turn from white to clear. Reapply after every use.

COVERAGE RATES

1 gallon (3.78 liters) of KLEEN KOTE will cover approx. 1,000 - 2,000 sq. feet (185 sq. meters) depending on the surface type being treated. Spray on for best performance and ease of application.

IMPORTANT INFORMATION

Never dispense KLEEN KOTE in a drum or container previously used to store acid. Do not use an applicator or sprayer used for acid. The acid residue cannot be removed from the drum, container or applicator and will cause KLEEN KOTE to separate. Do NOT remove the concrete from the paver during the paving process or you will remove the applied KLEEN KOTE. Re-apply KK 111 to all areas of the paver where concrete was cleaned or removed. Do NOT re-apply KK 111 in the morning if you sprayed the machine the night before. This will weaken the grip of the first application. Harsh chemicals are not needed to remove KLEEN KOTE. Soap and water can be used when required. Reapply KLEEN KOTE after every use and after every wash. KLEEN KOTE can be applied to damp surfaces but CANNOT be applied in rainy conditions.

***PREVENT KLEEN KOTE FROM FREEZING!
DO NOT MIX WITH OTHER RELEASE AGENTS OR CHEMICALS!*****FIRST AID PROCEDURES**

If contact with eyes occurs, immediately flush with water. If swallowed, do NOT induce vomiting. In either case, seek medical attention immediately. Additional information is available on the MSD sheet.

WARNINGS

Please keep this and all chemicals out of reach of children! Use this product only as directed. Non-stick product may cause slipperiness on vehicle controls and surfaces. Avoid spraying on braking surfaces where slipperiness may cause a loss of control.