

KLEEN KOTE™ - Concrete Paving Machine Instructions

REV. 022813

Spray KLEEN KOTE on once per job prior to placement, to protect the equipment from concrete stickage and also to help prevent rust. Vary the mix ratio to meet your needs. This product can also be used on your other concrete placing equipment.

RATIOS (MIX KLEEN KOTE TO WATER)

1 to 8 thru 1 to 11

TYPICAL COVERAGE RATES

1 gallon of mixed KLEEN KOTE will cover approx. 2000 sq. feet (185 meters), depending on the surface type. Spray on for best performance and ease of application.

1. DETERMINE YOUR MIX RATIO

Please see the above starting mix ratios. Ratios can be adjusted based upon your results. They may be adjusted up or down in one part increments to achieve optimum results. NOTE: The more concentrate you add the thicker and more protective KLEEN KOTE will be.

2. MIXING

Using a clean container, add KLEEN KOTE and water to achieve the recommended ratio for your application. Adding KLEEN KOTE to water and then adding more water will eliminate the need for mixing. Do **NOT** mix with diesel, fuels or oils. Do **NOT** mix with other release agents.

3. APPLICATION

KLEEN KOTE may be applied at any time. For best results, the application surface should be cleaned prior to application. Remove all other release agents before applying KLEEN KOTE.

4. SPRAYING

Spray on and then let change from white to clear before using the treated equipment. If KLEEN KOTE freezes on the surface you are treating, it will still work. Reapply after every use.

TIPS FOR USE

- Remove all previously used release agents from the concrete paving machine prior to applying KLEEN KOTE. This will eliminate any adverse reaction between KLEEN KOTE and the former release agents.
- For best results, spray the entire paver with KLEEN KOTE the night before you pour.
 - If you can't apply the product the night before your next pour, you can apply the product just prior to use. However, the KLEEN KOTE must turn from white to clear after it is sprayed on the equipment before you start paving.
- KLEEN KOTE deposits a thin film of reactive protection on the paver. Do not remove the concrete from the paver during the paving process or you will remove the applied KLEEN KOTE, causing the fresh layer of concrete to stick to the paver. KLEEN KOTE must be applied to all areas of the paver where concrete was cleaned or removed and can be re-applied at any time during the paving process.
- The paver should be sprayed every night regardless of whether or not you clean the machine prior to the next pour.
- KLEEN KOTE should be sprayed on the machine after every wash to help prevent rust will the machine is not being used.

NOTES

- Reapply KLEEN KOTE every time the machine is cleaned. This will protect the machine from corrosion when it is not in use.
- You do not have to wait for the paver to dry after power washing it. KLEEN KOTE may be applied directly to a wet paver.
- Do not reapply KLEEN KOTE in the morning if you have already sprayed the machine the night before. By spraying the paver again, you will weaken the grip of the first application of KLEEN KOTE.
- Once KLEEN KOTE has changed from white to clear, it will **NOT** wash off during rain. However, KLEEN KOTE can **NOT** be applied during rain because it will rinse off before the product changes from white to clear.
- In freezing weather, mix product as needed. Concentrate will not freeze however premix may freeze.

If you have any questions regarding the use of this product please feel free to contact Customer Support