

KLEEN KOTE™ - Hauling Equipment Instructions

REV. 030713

Use KLEEN KOTE to keep asphalt, concrete, mud, snow and ice from sticking to hauling equipment. It is an environmentally safe alternative to traditional release agents, diesels or other fuels. It also provides rust inhibiting qualities to help prevent corrosion.

RATIOS (MIX KLEEN KOT TO WATER)

1 to 8 thru 1 to 11 -- Depending Upon Results

TYPICAL COVERAGE RATES

1 gallon (3.78 liters) of mixed KLEEN KOTE will cover approx. 2000 square feet (185 square meters), depending on the surface type. Spray on for best performance and ease of application.

1. DETERMINE YOUR MIX RATIO

Please see the above starting mix ratios. Ratios can be adjusted based upon your results. They may be adjusted up or down in one part increments to achieve optimum results. **NOTE:** The more concentrate you add the thicker and more protective KLEEN KOTE will be.

2. MIXING

Using a clean container, add KLEEN KOTE and water to achieve the recommended ratio for your application. Adding KLEEN KOTE to water and then adding more water will eliminate the need for mixing. Do **NOT** mix with diesel, fuels or oils. Do NOT mix with other release agents.

3. APPLICATION

KLEEN KOTE may be applied at any time. For best results, the application surface should be cleaned prior to application. Remove all other release agents before applying KLEEN KOTE.

4. SPRAYING

Spray on and then let change from white to clear before using the treated equipment. If KLEEN KOTE freezes on the surface you are treating, it will still work. Reapply after every use.

TIPS FOR USE

- Remove all previous release agents from the dump bed prior to applying KLEEN KOTE to eliminate any adverse reaction between KLEEN KOTE and the former release agent.
- For asphalt and concrete hauling, spray KLEEN KOTE over the entire bed before EVERY load and before you put the truck away at night.
- For mud and snow hauling, spray KLEEN KOTE once a day prior to your first load. In freezing weather, the bed must be warmed indoors prior to applying KLEEN KOTE.
- KLEEN KOTE must turn from white to clear after it is sprayed on the bed before you start hauling.
- If you wash the truck with soap and water, you must re-apply KLEEN KOTE before hauling your next load.

NOTES

- **DO NOT** switch back and forth between KLEEN KOTE and other release agents due to incompatibility.
- You do not have to wait for the bed to dry after cleaning. KLEEN KOTE may be applied directly to a wet bed.
- KLEEN KOTE can be applied as a polish to the cab to keep asphalt, concrete, mud or snow from sticking to the surface. See VEHICLE INSTRUCTIONS for details on applying to the cab.
- KLEEN KOTE may also be applied to the wheels and undercarriage to keep asphalt, concrete mud and snow from sticking.
- In freezing weather, mix product as needed. Concentrate will not freeze however premix may freeze.

If you have any questions regarding the use of this product please feel free to contact Customer Support.