

KLEEN KOTE™ - Vehicle Polishing Instructions

REV. 030713

KLEEN KOTE is an excellent choice to polish your vehicles or equipment. In addition to protecting your vehicles from concrete, asphalt, mud and salt, KLEEN KOTE can be buffed to a high shine or misted on the front of your vehicle to prevent bugs and other road debris from sticking to your vehicle.

RATIO (MIX KLEEN KOTE TO WATER)

1 to 15 - For Polishing Applications

1. DETERMINE YOUR MIX RATIO

Please see the above starting mix ratios. Ratios can be adjusted based upon your results. They may be adjusted up or down in one part increments to achieve optimum results. **NOTE:** The more concentrate you add the thicker and more protective KLEEN KOTE will be.

- Ratios containing more water and less KLEEN KOTE will provide a higher shine.
- Ratios containing less water and more KLEEN KOTE will provide greater protection from stickage.

2. MIXING

Using a clean container, add KLEEN KOTE and water to achieve the recommended ratio for your application. Adding KLEEN KOTE to water and then adding more water will eliminate the need for mixing. Do NOT mix with diesel, fuels or oils. Do NOT mix with other cleaning or polishing agents.

3. APPLICATION

KLEEN KOTE may be applied at any time. For best results, the application surface should be cleaned prior to use. Remove all other chemicals and/or soaps before applying KLEEN KOTE.

4. SPRAYING / POLISHING

KLEEN KOTE is best applied with a spray applicator to small sections of the vehicle at a time.

- Mist KLEEN KOTE on, then polish it in with a damp cloth before the product changes from white to clear, until the film is barely visible.
- Then buff with a clean, dry towel. Reapply after every wash.

5. SUBSEQUENT CLEANINGS

For subsequent cleanings, you do not need to wash the entire vehicle with soap and water. Simply rinse or power wash any heavy build-up off the vehicle and repeat Step 4.

- For vehicles, without heavy build-up and having a prior application of KLEEN KOTE, the user may simply spray KLEEN KOTE on the vehicle and wipe with a damp rag. Then repeat Step 4 if desired.

TIPS FOR USE

DONT'S

- Do NOT mix KLEEN KOTE with anything but water.
- Do NOT allow KLEEN KOTE to come in contact with acids, soaps or other cleaning agents.
- Do NOT apply KLEEN KOTE to windows, as it may cause streaking. You will need to use window cleaner to remove it.
- Do NOT spray onto brake rotors.

DO's

- Do mix KLEEN KOTE in a clean container.
- Do wash the vehicle with soap and water prior to the first application of KLEEN KOTE. This is done to remove road grime and any built-up waxes or chemicals from past cleanings.
- Do be sure to rinse vehicle of all chemicals and soaps after washing and prior to applying KLEEN KOTE.
- Do apply KLEEN KOTE to under carriage of the vehicle at least once per week to help prevent build-up and corrosion.
 - On severely sun dried or acid washed paint KLEEN KOTE may need to be applied several times and allowed to soak in. This will help revitalize the color of the paint.

NOTES

- Vehicles that do not need a high polish can simply be power washed with water only, then sprayed with KLEEN KOTE and wiped down. The product does not have to be buffed.

AREAS THAT CAN BE POLISHED:

- Body, cab and wheels

AREAS THAT SHOULD NOT BE POLISHED:

- The undercarriage should be sprayed weekly to help prevent mud from sticking and corrosion. Wheels may be sprayed and left or they may be polished, depending upon your personal preference. Any time KLEENKOTE is sprayed and left to go clear, it will collect more dust but will provide greater protection.
- In freezing weather, mix product as needed. Concentrate will not freeze however premix may freeze.

If you have any questions regarding the use of this product please feel free to contact Customer Support