

KLEEN KOTE™ - Precast Concrete Instructions

KLEEN KOTE gives you the ability to adjust your release agent to work best with the concrete mix design and type of forms and liners that you are using. It is also safe for use on all types of forms.

REV. 030713

RATIOS (MIX KLEEN KOTE TO WATER)

- 1 to 11 - For Porous Surfaces
- 1 to 15 - For Non-Porous Surfaces

TYPICAL COVERAGE RATES

1 gallon (3.78 liters) of mixed KLEEN KOTE will cover approx. 2000 square feet (185 square meters), depending on the surface type. Spray on for best performance and ease of application.

1. DETERMINE YOUR MIX RATIO

Please see the above starting mix ratios. Ratios can be adjusted based upon your results. They may be adjusted up or down in one part increments to achieve optimum results. **NOTE:** The more concentrate you add the thicker and more protective KLEEN KOTE will be.

2. MIXING

Using a clean container, add KLEEN KOTE and water to achieve the recommended ratio for your application. Adding KLEEN KOTE to water and then adding more water will eliminate the need for mixing. Do **NOT** mix with diesel, fuels or oils. Do **NOT** mix with other release agents.

3. APPLICATION

KLEEN KOTE may be applied at any time. For best results, the application surface should be cleaned prior to application. Remove all other release agents before applying KLEEN KOTE. Do **NOT** allow the product to pool on the bottom of your forms. This will affect the surface quality. Use a fine mist tip to regulate the use of the product or mop up the pools for best results. If you choose to mop up the pools, do this with a mop that is used specifically for this task, **NOT** a mop used for clean-up purposes.

4. SPRAYING

Spray on and then let change from white to clear before using the treated equipment. If KLEEN KOTE freezes on the surface you are treating, it will still work. Reapply after every use.

TIPS FOR USE

- Based upon your results, you may adjust the ratio by adding more or less concentrate. The more concentrate that is added, the more reactive KLEEN KOTE will be. The less concentrate that is added, the less reactive it will be. Reducing the amount of concentrate will reduce the amount of dusting, if any, left behind.
- For best results, remove as much of the previous form release as possible to eliminate any adverse reaction between KLEEN KOTE and the former release agent.
 - If your forms have fresh oil or other release agents already applied, you must cast off the previously applied form release agent prior to applying KLEEN KOTE.
- KLEEN KOTE must be re-applied to the forms after EACH use. It can be applied at any time by spraying the entire forming system while either setting up or tearing down the system.
- Allow KLEEN KOTE to turn from white to clear on the face of the forms prior to pouring concrete.
- This product may also be applied to the backs of the forms to prevent splatters from sticking.

NOTES

- Be sure to apply the product to the entire forming surface to ensure a smooth and easy release.
- **DO NOT** switch back and forth between KLEEN KOTE and other release agents due to incompatibility.
- Once KLEEN KOTE has changed from white to clear, it will **NOT** wash off during rain. However, KLEEN KOTE can **NOT** be applied during rain because it will rinse off before the product changes from white to clear.
- If the forms are new, season them with KLEEN KOTE just as you would with oil.
- Proper vibration should be used to achieve the best surface finish. Please see our *General Vibration Facts* sheet for details.
- In freezing weather, mix product as needed. Concentrate will not freeze however premix may freeze.

If you have any questions regarding the use of this product please feel free to contact Customer Support.