

KLEEN KRETE™ - General Use Instructions

• **General Instructions for Using KLEEN KRETE**

- o KLEEN KRETE is quick and easy to use and works best when applied to dry, hardened concrete. Simply follow the tips and step by step instructions below to achieve the full benefits of this product.

• **Tips for Use**

- o Test KLEEN KRETE on an inconspicuous area prior spraying or brushing the entire item with product.
- o KLEEN KRETE's effectiveness is greatly reduced in cold weather where freezing conditions could cause the product to freeze prior to softening the concrete.
- o KLEEN KRETE's effectiveness is greatly reduced in hot conditions where direct sun will cause the product to evaporate prior to softening the concrete.
- o This product does not remove paint however power washers do. Use only as much pressure as you need. Using a "zero" tip on your power washer will allow you to direct the water where it needs to be. Keep the tip on a 45deg. angle to the item that you are power washing and move the tip as close or as far away as needed to effectively lift and remove the concrete.
- o Refer to the product MSD Sheet for additional product information.

• **Instructions**

o **Step 1 - Preparation**

- KLEEN KRETE is packaged ready-to-use and works best when applied to dry, hard concrete. Be sure to protect concrete floors surrounding the area where KLEEN KRETE will be applied.

o **Step 2 - Application**

- Spray or brush KLEEN KRETE onto the dry, hardened concrete that you wish to remove. It will initially foam slightly but will then subside. The product will continue to work even after the foaming action has stopped. Do NOT apply KLEEN KRETE to a hot surface. It will evaporate quickly and may damage the surface.

o **Step 3 – Let Product Work**

- Allow KLEEN KRETE to remain on the concrete for at least 30 minutes or until the concrete becomes soft to the touch. Heavier build-ups should be left overnight and lightly sprayed the next day approx. 10 minutes prior to removing the concrete. This is done to re-soften the concrete.

o **Step 4 – Remove Softened Concrete**

- After the concrete has softened, scrape or power-wash the concrete off the surface. If additional concrete remains subsequent applications of KLEEN KRETE will be necessary. Build-ups of a 1/4" (6mm) or more may require additional applications. The concrete must be allowed to dry before the next application.

• **Technical Notes**

- o KLEEN KRETE is a clear liquid with an amber cast. When applied to concrete the product will foam slightly.
- o KLEEN KRETE will not affect the finish on most equipment when used according to directions and can be used as a regular maintenance product. Rinse tools with soap and water after use. Always wear protective clothing and eye wear. Do NOT allow to freeze.

• **Specifications and Compliance**

- o N.A.C.E.(ASTM G-31): Non-Corrosive - CFR49 Section 173.24: Non-Corrosive - Biodegradable Oxygen Demand (B.O.D.) Test Factor (0.28): Biodegradable - DOT and IMO: Non-Hazardous - Canadian WHMIS Class "E".

• **If you have any questions regarding the use of this product please feel free to contact Customer Support by telephone: 800.801.7832 – 847.639.7272 or via email: support@4progressive.com.**